

SWAT+ modeling


How to add inflow hydrograph

PointID selection for the inlet

The point ID for the inlet is defined when we prepare the SWAT+ model in QSWAT+. We can verify it in QGIS using the Identify Features tool.

Implementation workflow using swatpluseditor

Edit SWAT+ Inputs → Point Source/Inlet → Edit Inlet Point → Set the time step to **“Daily”** and import the CSV file prepared for that specific inlet point.



To prepare the input file, we can export the empty recall file in .csv format, add the flow data (in volume, m³), and then import the updated file back into SWAT+.

Table: sample input file format for the inlet

jday	mo	day_mo	yr	ob_typ	ob_name	flo	sed	orgn	sedp	no3	solp	chla	nh3	no2	cbod	dox	sand	silt	clay	sag	lag	gravel	tmp
1	1	1	2005	pt_day	pt028	16343154.4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2	1	2	2005	pt_day	pt028	16465483.4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

SWAT+, Modeling

From: <https://www.hydrowiki.isnew.info/> - HydroCS Wiki

Permanent link: https://www.hydrowiki.isnew.info/swatplus_modeling?rev=1780076800

Last update: 2026-05-29 11:46 am

